User Care Manual

Care and Cleaning

Dust regularly with a soft, lint-free cloth or a lint roller to prevent staining from dust, dirt, and other unclean particles. A damp cloth may be used minimally to clean outer surfaces. Make sure surfaces are **dry** after finishing. Keep your product away from any abrasives that may damage the wood finishes or fabrics. Moisture and humidity may damage and otherwise deteriorate the wood frame. Keep your product out of excessive sunlight and extreme changes in temperature to preserve the integrity of your product.

Maintenance

Check periodically if the bolts and screws have loosened over time and tighten them accordingly. Dry and remove any moisture or other liquid particle build-ups from veneer finish, bolts and screws to prevent warping or rusting.